

Equipment and technical information



MEDION® E49363 (MD 88363) WEBCAM WITH STUDIO LIGHT



This information sheet is part of the user manual. Read the user manual carefully and in full. This information sheet does not replace the user manual. Read the chapter entitled “Safety” in the user manual before you start and follow the detailed instructions for setup and connection.

Information about this user manual



Thank you for choosing our product. We hope you enjoy using this device. Please read the safety instructions and the user manual carefully before using the device for the first time. Note the warnings on the device and in the user manual. Always keep the user manual close to hand. If you sell the device or give it away, please ensure that you also pass on this user manual. It is an essential component of the product.

Explanation of symbols

If a block of text is marked with one of the warning symbols listed below, the hazard described in that text must be avoided to prevent the potential consequences described there from occurring.



DANGER!
Warning: risk of fatal injury!



WARNING!
Warning: risk of possible fatal injury and/or serious irreversible injuries!



CAUTION!
Warning: risk of minor and/or moderate injuries!



More detailed information about using the device!

Proper use

- Your device can be used in the following ways:
This product is intended for recording videos and taking photographs on a computer/notebook with USB ports.
- The device is only intended for private use and not for industrial/commercial use. Please note that we shall not be liable in cases of improper use:
 - Do not modify the device without our consent and do not use any auxiliary equipment that we have not approved or supplied.
 - Only use replacement parts or accessories that we have supplied or approved.
 - Comply with all the information in this user manual, especially the safety instructions. Any other use is considered improper and can cause personal injury or property damage.
 - Do not use the device in potentially explosive atmospheres. This includes petrol stations, fuel storage areas and areas where solvents are processed. This device must also not be used in areas with particle-laden air (for example, flour or wood dust).
 - Do not expose the device to extreme conditions. Avoid:
 - high humidity or wet conditions
 - extremely high or low temperatures

- direct sunlight
- naked flames.

Safety instructions

Operating safety



WARNING!
Risk of injury!

- Risk of injury to persons with limited physical, sensory or mental abilities (for example, partially disabled people or older people with limited physical or mental abilities) or to those without experience and knowledge (such as older children).
- ▶ This device can be used by children over the age of 8 and by persons with reduced physical, sensory or mental abilities or by those without experience and/or knowledge, if they are supervised or have been instructed in the safe use of the device and have understood the dangers that result from it.
 - ▶ Children must not be allowed to play with the device.
 - ▶ Cleaning and user maintenance must not be carried out by children.
 - ▶ Children younger than 8 should be kept away from the device and the connection cable.
 - ▶ Keep all packaging materials used (bags, pieces of polystyrene etc.) out of reach of children.
 - ▶ Do not allow children to play with the packaging material.



There is no right of recourse for lost data or for consequential damage caused by data loss. This product has been designed for use with a PC.

- ▶ Follow the safety instructions for the computer to which you connect the device.

Installation location

- ▶ Set up and operate the device on a stable, level and vibration-free surface.
- ▶ Keep the device away from moisture, water droplets and spray, and avoid dust, heat and direct sunlight.

Package contents

Check whether all the items in the delivery are present. Contact us within 14 days after purchase if any items are missing. Always specify the serial number when making enquiries.
The following components are supplied with your webcam:

- Webcam
- Documentation



DANGER!
Risk of choking and suffocation!

Packaging film can be swallowed or used improperly, creating a risk of choking and suffocation.


- ▶ Keep packaging material such as plastic film or plastic bags away from children.

Equipment and technical information

MEDION® E49363 (MD 88363) FULL HD WEBCAM WITH AUTO FOCUS


MEDION®

Device overview



Getting started

- ▶ Switch on the computer and all connected peripheral devices (monitor, printer etc.) and wait until the operating system is fully started.
- ▶ Open up the holder and clip the webcam onto the top of your monitor as shown.



- ▶ Connect the webcam to a free USB port on your computer.
 - ▶ Drivers are installed automatically.
- There is a thread on the underside of the holder for use with a tripod.
- ▶ Close the holder and screw the webcam onto the tripod.
 - ▶ Tap the lighting touch switch several times to set the desired lighting level.

Declaration of conformity

MEDION AG hereby declares that this device complies with the fundamental requirements and the other relevant provisions of:

- EMC Directive 2014/30/EU
- RoHS Directive 2011/65/EU.

Cleaning

- ▶ Make sure that the device is kept clean. Before cleaning the device, disconnect all cable connections to the PC. Clean the device and all other components with a damp cloth. Do not use solvents or corrosive or gaseous cleaning agents.

Disposal

**PACKAGING**

Your device has been packaged to protect it from damage in transit. The packaging is made of materials that can be recycled in an environmentally friendly manner.

**DEVICE**

All old devices marked with the symbol shown must not be disposed of in normal household waste. In accordance with Directive 2012/19/EU, the device must be properly disposed of at the end of its service life. This involves separating the materials in the device for the purpose of recycling and minimising the environmental impact. Take old devices to an electrical scrap collection point or a recycling centre. Before doing so, remove the batteries from the

device and take them to a separate collection point for used batteries.
Contact your local waste disposal company or your local authority for more information on this subject.

General technical specifications

Webcam	
Connections	1 x USB cable, approx. 1.5 m
USB TYPE	TYPE -A
Input voltage	5 V  600 mA
Dimensions (L x D x H)	Approx. 92 x 57.5 x 46.3 mm
Weight	Approx. 103 g
Resolution	Max. 2592 x 1944



Service information

- Please contact our customer service team if your device ever stops working in the way you want or expect it to. There are several ways for you to contact us:
- In our Service Community, you can meet other users as well as our staff, and you can also share your experiences and pass on your knowledge. You will find our Service Community at community.medion.com.
 - Alternatively, use our contact form at www.medion.com/contact.
 - You can also contact our customer service team via our hotline or by post.

Opening times	Hotline number UK
Mon – Fri: 08.00 – 20.00 Sat – Sun: 10.00 – 16.00	 0333 3213106
Service address	
MEDION Electronics Ltd. 120 Faraday Park, Faraday Road, Dorcan Swindon SN3 5JF, Wiltshire United Kingdom	



You can download this and many other sets of operating instructions from our service portal at www.medionservice.com.
You can also scan the QR code on the side of the screen, to download the operating instructions onto your mobile device from the service portal.

Legal notice

Copyright © 2022
Date: 8. June 2022, 12:31 pm
All rights reserved.
This user manual is protected by copyright.
Mechanical, electronic and any other forms of reproduction are prohibited without the written permission of the manufacturer.
Copyright is owned by the company:
MEDION AG
Am Zehnthof 77
45307 Essen
Germany
Please note that you cannot use the above address for returns. Please always contact our customer service team first.