

Zu Ihrer Sicherheit



GEFAHR für Kinder

- Halten Sie Kinder vom Verpackungsmaterial fern. Die Tüten und Folien sind kein Spielzeug. Achten Sie darauf, dass diese nicht über den Kopf gestülpt oder Teile davon verschluckt werden. Erstickungsgefahr!

VORSICHT - Verletzungsgefahren und Sachschäden!

- Halten Sie den Artikel fern von spitzen oder scharfkantigen Gegenständen.
- Füllen Sie nicht zu viel Wasser in den Artikel. Beachten Sie die Wassermengentabelle zur richtigen Wassermenge.
- Verwenden Sie nur kaltes bzw. lauwarmes Leitungswasser. Die Wassertemperatur **darf nicht höher als 38 °C** sein.
- Das eingefüllte Wasser darf maximal 1 Jahr im Kissen verbleiben. Danach muss es aus Hygienegründen ausgewechselt werden.


Zur Pflege

Der Artikel kann in der Waschmaschine gereinigt werden. Lassen Sie das Wasser vorher aus dem Kissen. Beachten Sie die Pflegehinweise auf dem Einnähetikett.


Die richtige Wassermenge

Festigkeitsgrad	Wassermenge in Liter
weich	ca. 2 L
mittel	ca. 3 L
hart	ca. 4 - 5 L


Wasser einfüllen




1. Drehen Sie die Verschlusskappe mit dem Trichter auf.




2. Zum Einfüllen von Wasser setzen Sie den Trichter auf die Öffnung und drehen ihn fest.



3. Stellen Sie das Kissen aufrecht hin und füllen Wasser ein (siehe Wassermengentabelle oben).



4. Drücken Sie die Restluft vorsichtig aus dem Kissen.



5. Setzen Sie die Verschlusskappe wieder auf und drehen Sie sie mit dem Trichter bis zum Anschlag fest.



Wenn Sie im Kissen noch ein „Schwappen“ hören, befindet sich noch Restluft im Kissen. Entfernen Sie die Restluft wie beschrieben.



Water Pillow

Product information

Tchibo GmbH D-22290 Hamburg · 98140AS6X3VIII · 2018-01 · 367 270

en

For your safety

DANGER to children

- Keep the packaging material out of the reach of children. The plastic bags and protective films are not toys. Make sure that children do not pull them over their heads and that no parts of them are swallowed.
Risk of suffocation!

CAUTION – risk of injury and material damage!

- Keep the product away from pointed or sharp-edged objects.
- Do not fill the product with too much water. Please refer to the water quantity table for the right amount of water.
- Use only cold or lukewarm tap water.
The water temperature **must not be higher than 38 °C**.
- Once filled, the water must not remain in the pillow for longer than 1 year. Once a year has passed, it must be replaced for hygiene reasons.


Care

The product can be cleaned in a washing machine. Empty the water out of the pillow first. Please observe the care instructions on the sewn-in label.


The right amount of water

Degree of firmness	Amount of water in litres
soft	approx. 2 litres
medium	approx. 3 litres
hard	approx. 4-5 litres


Filling with water




1. Open the locking cap by turning it using the funnel.




2. To fill with water, place the funnel on the opening and turn it tight.



3. Place the pillow upright and pour in the water (see water quantity table above).



4. Carefully press the remaining air out of the pillow.



5. Refit the locking cap and, using the funnel, turn it as far as it will go until tight.



If you can still hear a “sloshing” noise inside the pillow there is still some air in the pillow. Remove the remaining air as described.

Made for:
Tchibo GmbH, Überseering 18,
22297 Hamburg, Germany